

Internal Partition batts

These instructions should be read in conjunction with local standard MS 1020:2022 and all applicable local, state and federal building regulations. Before you start installing, please make sure you are familiar with our Health and Safety Information contained in this document. Ensure that you use tools and equipment that are suitable for the intended application. This will include suitable safety equipment.

DO NOT START WORK UNTIL THE SITE IS SAFE!

Assess the wall condition and structure together with the method of installation you are to use based on the appropriate requirements established in the building code, site assessment and or plans provided.

TOOLS REQUIRED:

- Sharp knife for trimming insulation
- Ladder
- Suitable clothing (see our Health and Safety Information)
- Tape measure

STEP 1

- Determine the most suitable product for your project. Walls can be insulated using rolls or batts.
- Insulation is available in varying widths and thicknesses to suit most framing spaces. Please check Knauf Insulation's product guide for the most suitable product for your application.
- To calculate the number of packs needed, determine the area (m²) to be insulated by multiplying the length by the width or wall height. The number of m² of insulation material is clearly marked on each pack. Divide the total area to be insulated by the m² in a pack to determine the number of packs required (don't forget to round up to the nearest whole pack). Allowances should be made for areas that are unable to be insulated.

STEP 2

- Don't take the insulation out of the packaging until you're in position and ready to install.
- Before installation check that the product selected matches the specification.
- Ensure that the insulation has lofted to the nominal thickness, if required, gently agitate the insulation by gently shaking or bouncing it on its side until it recovers to thickness stated on the label.
- Where installing around wall lights or heat sources consult the appliance manufacturer's instructions for appropriate clearances.

STEP 3

- When installing insulation between framing members, ensure that you achieve a snug fit avoiding any gaps, tucks and folds.
- It is recommended that you select products that have the same thickness as the cavity. In circumstances where the cavity is deeper than the product selected, adequate support must be provided.
- Make sure insulation fits snugly against top and bottom wall plates. The front face of the batt should be flush with the inside face of the framing.
- For metal frame walls, install insulation according to the relevant building code. Friction fit one side of the batt into the metal C-channel and butt the other edge against the metal stud. Install insulation to cover the full height of the wall.
- Use off cuts to insulate small and hard to fit areas.

STEP 4

- Attention to detail is very important. Make sure all areas are insulated, behind electrical outlets, plumbing and services.

STEP 5

- Complete a final check of the installation ensuring all areas have been insulated and that you have an even and consistent layer of insulation.
- Finish your project by removing all packaging and disposing of all rubbish and excess insulation responsibly.

PRE-LINING INSPECTION

- Glasswool insulation is a compressible material and is manufactured to achieve the declared performance at the labelled nominal thickness.
- A pre-lining inspection must be completed to ensure that the product has achieved its nominal thickness and ensure that the product is not protruding beyond wall stud thickness, restricting external ventilation cavities or pressuring the wall linings.
- In internal walls, where the cavity is filled with insulation, installers must take extra care to ensure that the lining material maintains full contact with the framing.

We recommend that once completed another person checks the work to ensure it has been installed according to required standards.

Health and Safety Information

SAFETY WARNINGS AND HAZARDS

- You must turn the switchboard 'Off' before entering the work space, and, if in any doubt about how to turn the power 'Off', you must consult a licensed electrician.
- Working in areas that contain live electrical wiring is extremely hazardous. Take extreme care to avoid touching any live overhead electrical lines, supply cables or any other live cables in the workspace.
- Defective electrical cables, exposed terminals and conductors of electrical equipment such as light fittings and fans can cause burns and electric shocks please exercise caution when working near such hazards – check with an electrician if you are unsure if the cabling is safe.
- Working in hot and poorly ventilated areas when installing insulation can be dangerous.
- Working at heights, when installing insulation can be dangerous.

BEFORE INSTALLATION

- You must turn the switchboard 'Off' and, if in any doubt about how to turn the power 'Off', consult a licensed electrician.
- Do not enter the workspace for the purposes of the pre-work inspection or the installation until you are satisfied that the power has been isolated. Even after isolating the power via the switchboard there may still be an electrical mains cable in either the ceiling or underfloor space that is live.
- Complete a pre-work assessment before installation to identify safety hazards which may include but are not limited to the following:
 - › access to the roof area,
 - › working at heights,
 - › electrical safety hazards,
 - › adequate ventilation of the work area and
 - › nails and sharp objects on the ground
- Before commencing work you must have systems in place to reduce risks identified in the pre-work assessment such as but which are not limited to:
 - › systems to prevent falling when working at heights.
 - › ventilate the working area if possible.
 - › cover exposed skin. When working in an unventilated area, wear a disposable face mask.
 - › rinse hands in cold water before washing.
 - › wear goggles when working overhead.
 - › clean using vacuum equipment.

DURING INSTALLATION

- Work with another person and maintain contact throughout both the assessment and installation process.
- Only open bags as required.
- Wear appropriate clothing for the job such as long sleeved top, flat rubber sole shoes, gloves conforming to SS ISO 21420:2023 and ventilated non-fogging dust resistant goggles conforming to SS 473, and a P2 dust mask.
- Avoid eye contact with dust or fibres to minimise eye or skin contact and inhalation during handling.
- Avoid installing insulation in hot weather and at the hottest part of the day.
- Under no circumstances must fixing devices in ceiling spaces or under floors, or in proximity to electrical wiring, be of metal or other conductive material.

PROVEN PERFORMANCE

- Preferred by professional installers concerned with quality, appearance and productivity.
- Excellent acoustical properties reduce sound transmission in the home when properly installed.

ELECTRICAL SAFETY CONSIDERATIONS BEFORE ISOLATING POWER

- Locate and review the main switchboard.
- Ensure you understand if there is a switchboard and how power can be safely isolated.
- Ensure you understand the direction of the 'On' and 'Off' position of the main switch (NOTE: the 'Off' position is not always as it seems - check with an electrician if you are unsure).
- Before installation, switch 'Off' the electricity supply at the main switchboard (check with an electrician if you are unsure if power can be turned 'Off' at the switchboard).
- Be aware that even after isolating the power via the switchboard there may still be an electrical mains cable in either the ceiling or underfloor space that is live.
- Take extreme care to avoid touching any live overhead electrical lines, supply cables or any other live cables in the workspace.

Health and Safety Information

PROCEDURE FOR ISOLATION - CERAMIC FUSES (IF IN DOUBT YOU MUST CONSULT A LICENSED ELECTRICIAN)

- Ceramic fuses are typically found in older style homes.
- Identify if any fuse is deactivated.
- Check if there are any fuses currently in the 'Off' position, take note of them.
- Place a strip of electrical tape over main switchboard after it is turned 'Off'.
- Apply additional strips of electrical tape over the deactivated fuse and any individual isolator in the 'Off' position as a reminder to leaving it in the 'Off' position once the re-activation procedure has been completed.
- If you find a fuse plug out of its socket, whilst the main isolator is in the 'Off' position, place electrical tape over its respective switch and one over the fuse socket opening.
- DO NOT touch the internal metal fittings.
- Place a written note on the switchboard enclosure saying "WORK IN PROGRESS - DO NOT SWITCH ON" to advise the power is 'Off' and work is occurring.
- Check to ensure the lights and appliances, within the home, previously left on are no longer operating to confirm the switchboard is now isolated.
- The original person who placed the isolation tag is the only one who can re-activate the power. Advise occupants of this requirement.

PROCEDURE FOR ISOLATION CIRCUIT BOARD (IF IN DOUBT YOU MUST CONSULT A LICENSED ELECTRICIAN)

- Circuit boards are typically found in modern homes.
- Check if there are any switches currently in the 'Off' position, take note of them.
- Place a strip of electrical tape over switchboard after it is turned 'Off'.
- Apply additional strips of electrical tape over any deactivated fuses or individual switches in the 'Off' position after isolating the switchboard as a reminder to leave it in the 'Off' position once the re-activation procedure has been completed.
- Turn 'Off' all individual switches on the circuit board.
- Place a written note on the switchboard enclosure saying "WORK IN PROGRESS - DO NOT SWITCH ON" to advise the power is 'Off' and work is occurring.
- Check to ensure the lights and appliances within the home previously left on are no longer operating to confirm the switchboard is now isolated.
- The originator that placed the isolation tag is the only one who can re-activate the power. Advise occupants of the requirement.

REACTIVATING THE POWER

- After the completion of the installation, switch the switchboard to the 'On' position (for ceramic fuse board), but for a circuit board, switch the switchboard 'On' and then each individual power isolator on one at a time. The taped switches in the 'Off' position should stay switched 'Off'.
- WARNING: If you cannot reconnect power please ensure you seek assistance from a qualified electrician.

SUITABLE CLOTHING

- When handling any insulation material, especially in enclosed poorly ventilated areas and/or overhead, the use of suitable eye protection conforming to SS 473 will greatly reduce contact with dust or fibres.
- Wear suitable loose fitting clothes, including long sleeved shirts, long pants, cap and gloves.
- A suitable dust mask is recommended when working in confined, poorly ventilated and dusty areas.